

## Copy Regular Slide (135 format)

1. **Log into the computer (S2).**

2. **Prepare the scanner.**

a. Turn on the scanner **(M2)**.

b. Pick up the right slide template which contains



c. Put one slide into the slide template, and the template looks like. You can put up to 12 slides per template.



d. Open the scanner cover, then attach the slide template on the glass. And the top view is



e. Close the scanner cover.

3. **Transfer the slides.**



a. Press once on the scanner frontal panel.

b. The 'EPSON Scan' software interface will pop up in the computer.



c. Press on the 'EPSON Scan' interface, and the scanner is scanning the slides.

d. After a while, a folder will pop up, and it contains the scanned slides. Now, you can copy these files to your own USB drive.

4. **Quit the computer (S2).** Your scanned slides in the computer will be deleted automatically.

5. **Remove the slides.**

a. Open the scanner cover.

b. Remove the slide template.

c. Open the slide cover, then remove the slides.

6. **Turn off the scanner (M2).**